



TIMOR S.J.
Z.BACH M.BUCH
 ASTRONOMÓW 1
 80-299 GDAŃSK, POLAND
 TEL: + 48 58 781 09 88

www.timor.pl

e-mail: timor@timor.pl

BEARINGS MANUFACTURED BY:



ŁOŻYSKA ŚLIZGOWE / SLIDE BEARINGS

ITEM	DESCRIPTION	PART NO.	DRAWING NO.
A. SULZER AL 20/24			
1	CON ROD BEARING (BUSH)	H33021	3-107.032.074
2	MAIN BEARING	H12020	2-107.032.112
3	MAIN BEARING U.S./0,4/	H12020	2-107.234.929
4	MAIN BEARING U.S./0,8/	H12020	2-107.234.929
5	MAIN BEARING U.S./1,2/	H12020	2-107.234.929
6	CON ROD BEARING	H33016	1-107.034.191
7	CON ROD BEARING U.S./0,4/	H33016	1-107.230.988
8	CON ROD BEARING U.S./0,8/	H33016	1-107.230.988
9	CON ROD BEARING U.S./1,2/	H33016	1-107.230.988
10	THRUST WASHER	H12010	2-107.032.111
11	THRUST WASHER U.S./0,4/	H12010	2-107.084.355
12	THRUST WASHER U.S./0,8/	H12010	2-107.084.355
13	THRUST WASHER U.S./1,2/	H12010	2-107.084.355
B. SULZER AL 25/30			
14	CON ROD BEARING (BUSH)	H33021	756.1.334.000
15	MAIN BEARING	H12020	2-107.234.937
16	MAIN BEARING U.S./0,4/	H12020	1-107.104.564
17	MAIN BEARING U.S./0,8/	H12020	1-107.104.564
18	MAIN BEARING U.S./1,2/	H12020	1-107.104.564
19	CON ROD BEARING	H33016	1-107.034.969
20	CON ROD BEARING U.S./0,4/	H33016	1-107.230.984
21	CON ROD BEARING U.S./0,8/	H33016	1-107.230.984
22	CON ROD BEARING U.S./1,2/	H33016	1-107.230.984
23	THRUST WASHER	H12010	1-107.033.974
24	THRUST WASHER U.S./0,4/	H12010	1-107.031.992
25	THRUST WASHER U.S./0,8/	H12010	1-107.031.992
26	THRUST WASHER U.S./1,2/	H12010	1-107.031.992
C. SULZER ATL 25/30			
27	CON ROD BEARING SHELL	H33016	1-107.102.887
28	CON ROD BEARING U.S./0,4/	H33016	1-107.230.985
29	CON ROD BEARING U.S./1,0/	H33016	1-107.230.985
30	CON ROD BEARING U.S./2,0/	H33016	1-107.230.985
D. SULZER ZL 40/48			
31	CAM SHAFT BEARING	K42601	2-107.021.565
32	THRUST WASHER	K12061	2-107.022.538
33	PLAIN BEARING BIG (UPPER & LOWER)	K12051/K33220 (U) K33210 (L)	1-107.082.828 1-107.123.502
34	MAIN BEARING	K12001	1-107.110.437
35	THRUST BEARING RING HALVES	K42605/K42611	2-107.023.345
E. SULZER ZA 40S / ZAL 40S			
36	UPPER/LOWER BEARING SHELL	KS42171 (U) KS42172 (L)	2-107.187.938 2-107.187.939
37	LOWER BEARING RING HALVES	KS42180	2-107.187.776
F. SULZER S 20			
38	CON ROD BEARING (BUSH)	3301/A108	2-107.231.004
39	UPPER MAIN BEARING SHELL	1201/A002	1-107.230.486a
40	LOWER MAIN BEARING SHELL	1201/A003	1-107.231.664
41	UP MAIN BEARING SHELL U.S./0,4/	1201/A002	1-107.232.352
42	LR MAIN BEARING SHELL U.S./0,4/	1201/A003	1-107.232.327
43	UP MAIN BEARING SHELL U.S./1,0/	1201/A002	1-107.232.352
44	LR MAIN BEARING SHELL U.S./1,0/	1201/A003	1-107.232.327
45	UP MAIN BEARING SHELL U.S./2,0/	1201/A002	1-107.232.352
46	LR MAIN BEARING SHELL U.S./2,0/	1201/A003	1-107.232.327
47	CON ROD BEARING SHELL	3301/A109	1-107.230.531
48	CON ROD BEARING SHELL U.S./0,4/	3301/A109	1-107.232.382
49	CON ROD BEARING SHELL U.S./1,0/	3301/A109	1-107.232.382
50	CON ROD BEARING SHELL U.S./2,0/	3301/A109	1-107.232.382
51	THRUST WASHER	1201/A001	2-107.231.674
G. SULZER S 20 & AL 20/24 & A25/30			
52	BEARING BUSH	H 73014	141.1.0522.0005
53	BEARING BUSH	H 74103	4-107.030.815